

## TW-7700

Digital Line Tracer



## **Operating Manual**

FISHER RESEARCH LABORATORY

# **CONTENTS**

$\operatorname{Description}$	g.	3
Transmitterp	g.	4
Receiverp	g.	5
Accessoriesp	g.	7
Operating Instructionsp	g.	8
Depth Accuracy p	g.	9
Specifications p	g.	10
Using Headphonesp	g.	11
Treasure Hunter's Code of Ethics p	g.	11

## **DESCRIPTION**

The TW-7700 Digital Line Tracer consists of a transmitter, receiver, ground-plate/ground-rod assembly, carrying case (hard or soft), and an operators manual. The TW-7700 is a single frequency line tracer.

The TW-7700 is an active locating line tracer. There are three methods of active locating that an operator can use to trace a utility. The **conductive** method is the most preferred method, since a strong transmitter signal is transmitted through the intended target. The **inductive** method is the easiest method to use. but may not yield the best results. When a direct connection is not available, but the operator has good knowledge of where one point of the utility may be. the operator can place the Transmitter over the utility making sure that the arrow on top of the transmitter is parallel to the path of the utility. The third method of active locating involves using the **coupling clamp** accessory. The coupling clamp is used when the utility is exposed, but a direct connection is not available. The clamp jaws are opened and placed around the utility. The clamp never makes a direct connection with the utility, that is, the utility can move freely with the clamp around it.

The features of the TW-7700 make it a very easy and practical instrument in today's world of underground locating.

## TW-7700 TRANSMITTER

#### **Transmitter**

Located on the transmitter are the power mode and the accessory output. The power mode enables the operator to turn the transmitter on or off, and to check the condition of the batteries. When checking the batteries, a reading if 50 or greater on the display meter indicates that batteries are usable.

The accessory output is for the ground plate/ground rod assembly, and for the coupling clamp. There is a Red LED light that blinks when the transmitter is on. The batteries are located underneath a lid on top of the transmitter housing.





## TW-7700 RECEIVER

#### Receiver



#### **Controls**

#### Mode

This button does not have a function on the TW-7700. (It allows users of the **TW-8800** Multi-Frequency Line Tracer to change frequencies.)

## Power On/Off

Turns the receiver on or off.

### Light

side of the display screen.

Bat


screen.

## Vol(up)/Vol(down)

Increases or decreases the volume of the speaker.

## Depth

the depth to the center of the target.



### Display

#### **Frequency Modes**

The frequency at which the receiver is operating.

### << Left/Over Target>/Right>>

Indicates where the receiver is in relation to utility.

### **Numeric Display**

Serves a dual function:

- Relative signal strength of the transmitted signal (% shown). Responds in conjunction with the bar graph.
- Depth to the center of the target (when DEPTH pad is pressed IN or CM shown)

### Light

Indicates the display is lit (activated by pressing LIGHT pad).

### **Bar Graph**

Serves three purposes:

- Responds in conjunction with signal strength.
- Visual indicator for battery test (when BAT pad is pressed).
- ${}^{\bullet}\text{Volume loudness indicator}$  (when VOL(up)/VOL(down) is pressed.

## **Replace Batteries**

When the receiver batteries fall below a nominal level, RE-PLACE BATTERIES will be displayed.

### No Signal

When no signal is received by the receiver, NO SIGNAL will display. This response may be due to the transmitter not being turned on, or the transmitter and receiver not be set at the same frequency.

## **ACCESSORIES**


## **Coupling Clamp**

The coupling clamp is useful when the utility is exposed, and a direct connection is not possible. It is plugged into the same plug-in socket as the ground-plate/ground-rod assembly. The coupling clamp only operates at the 82 kHz frequency. The coupling clamp will fit around utilities that are 3-¼ inches in diameter or smaller. The length of the cable is approximately 10 feet.

#### **Coupling Clamp Applications Diagram**

- A. The coupling clamp is for all tracing applications with conductors exposed; exception, an open circuit at line's termination.
- B. A ground must be provided for the proper current flow when the coupling clamp is used at a termination.
- C. The coupling clamp must be used between the grounding and where the line goes underaround.

- D. Trace signal will return to ground when incorrectly coupled.
- E. Signal will be transmitted in both directions when connecting is midway in a long conductor.
- F. Drop lines or laterals divide the signal strength in half at each junction.



#### **Headsets**

Fisher Research Laboratory has a variety of headsets available.

- Ultra-quiet deluxe Fisher Phones. High quality sound while reducing the outside noise.
- Standard Stereo Headphones
- Single Earpiece Headset. Enables the operator to effectively listen to the TW-7700 and remain aware of noise in close proximity.

## **OPERATING INSTRUCTIONS**

The following instructions are designed for a safe and effective method of line tracing and utility avoidance. Some of the steps may not be applicable in all situations. The underlying guideline is that operator safety must be maintained at all times. Use of safety equipment, extra personnel, and up to date as-built plans should be considered when necessary.

#### **INITIAL SCAN**

Set-up Transmitter either Inductively or Conductively

#### Inductive

Be aware of air coupling, the transmitted signal travelling to the Receiver via the air, not the utility.

#### Conductive

Connect the ground plate/ground rod assembly to the transmitter. Connect the red lead to the non energized utility. Connect the black lead to the ground plate/ground rod. Place the plate/rod at a 90 degree angle in reference to the utility. Be sure not to place the wires over any other utility.

After transmitter set-up, move away from the point of connection (or Induction) about 25 feet (8 meters). Sweep a circle around the point of connection. Initially, disregard the LEFT/RIGHT indicator and rely on the signal strength readout. Make note of the high readings. These are areas that need to be traced/examined in more detail.

### **Tracing**

After locating the point(s) where the signal strength was the highest, return to that/those points and start tracing your utility. This is where the LEFT/RIGHT indicator is very helpful. Swing the receiver from left to right and listen for the change of tone. When the target is to the RIGHT of the receiver, the tone is pulsed tone. As the receiver gets closer to the target, the pitch gets higher. When the target is to the LEFT of the receiver, the tone is a continuous tone. As the receiver gets close to the target, the pitch also becomes higher. When the receiver is over the target, OVER TARGET is displayed on the display screen, and the tone is at its highest peak sound.

## **Depth Measuring**

When an OVER TARGET response is displayed, position the blade of the receiver directly over the utility and place the tip on the ground. Hold the receiver steady, press and hold the DEPTH pad. Depth will be measured to the center of the utility.

## **DEPTH ACCURACY**

Depth measurement is a feature of the TW-7700. Accuracy is defined on an ideal target, that is, one that is continuous, a good conductor, and not surrounding by other utilities. There are factors that can cause the operator to question the accuracy of the utility being traced.

#### **Inductive Transmitter Setup**

Inductively, only a small portion of the signal attaches itself to the utility. With a weakened signal, trace should be accurate, but depth may not. The conductive method will yield better results.

### Low Receiver Signal Strength

When the signal strength falls below 20-25%, depth readout may not be accurate. It would be beneficial to move the transmitter to a closer point of contact.

## **Nearby Utilities**

Close, nearby utilities may have some influence on the accuracy of the Depth readout. This is more prone to happen in the higher frequencies where signals can jump to nearby utilities. Switching to a lower frequency can give better results.

#### Moisture

Ground that is too dry or overly saturated may skew the depth readout.

"T's", elbows, or splits in the utility can distort the transmitted signal in that general area.



**WARNING:** Do not connect output leads to a live (energized) utility. Please prevent shock hazard and equipment damage.

## **SPECIFICATIONS**

Subject to improvement or modification without notice.

#### **RECEIVER**

Depth Accuracy+1 inch per foot in nominal conditions				
Readout UnitsInches or cm (factory preset)				
Left/Right GuidanceAudio: continuous tone=Left,				
pulsed tone=Right. VCO (varying pitch) output for easy over				
target location. Visual: Left/Right/				
Over Target messages				
Signal Strength Digital Numeric Readout (0-99%)				
& Bar Graph				
Sensitivity AdjustAutomatic				
LCD BacklightIncluded				
Battery TestAutomatic Low Battery alert				
Push button readout				
Battery TypeSix "C" cells				
Battery Life80 Hours				
Weight				
Operating Temp $4^{\circ}$ to $+140^{\circ}$ F (-20° to $+60^{\circ}$ C)				

## **TRANSMITTER**

Output Frequency	. 82kHz,
Output Power (nominal)	5Watts,
Battery Test	. Yes
Battery Type	.Two 6 Volt lantern batteries
Battery Life	.80 Hours
Weight	. 5.0 lbs.

Fisher Research Laboratory does not warrant suitability to specific use. Fisher Research Laboratory shall in no event be liable for any direct, incidental, consequential or indirect damages.

## **USING HEADPHONES**

Using headphones (not supplied) improves battery life, and prevents the sounds from annoying bystanders. It also allows you to hear subtle changes in the sound more clearly, particularly if searching in a noisy location. For safety reasons, do not use headphones near traffic or where other dangers are present. This device is to be used with interconnecting cables/headphone cables shorter than three meters.

## TREASURE HUNTERS' CODE OF ETHICS

#### LETS PRESERVE OUR TREASURED SPORT!

Laws governing the use of metal detectors are becoming more and more common. In many countries, the use of metal detectors is illegal or severely restricted. Don't let this happen in your area.

- Always check Federal, State, County and local laws before searching.
- Respect private property and do not enter private property without the owner's permission.
- Take care to refill all holes and try not to leave any damage.
- Remove and dispose of any and all trash and litter found.
- Appreciate and protect our inheritance of natural resources, wildlife and private property.
- Act as an ambassador for the hobby, use thoughtfulness, consideration and courtesy at all times.
- Never destroy historical or archaeological treasures.
- All treasure hunters may be judged by the example you set; always conduct yourself with courtesy and consideration of others.



## QUALITY

Fisher detectors are renowned for their quality. Each detector is hand crafted in the USA with pride

## PERFORMANCE

The worldwide underground utility industry relys on Fisher.
Our instruments are durable, dependable, and locate deeper.

## REPUTATION

Fisher produced the first patented metal detector in 1931. For over 70 years, the Fisher logo has been a mark of excellence.

## 2 - YEAR LIMITED WARRANTY

Fisher believes in the products we produce and backs this belief with a 2 year limited warranty.

Proof of purchase is required to make a claim under this warranty.

### NOTE TO FOREIGN COUNTRY CUSTOMERS

This warranty may vary in other countries, check with your distributor for details.

Factory warranty follows the channel of distribution. Warranty does not cover shipping costs.

## SERVICE

Fisher is committed to providing you, our valued customer, with superior service. Each and every instrument is rigidly tested and carefully inspected during assembly and before shipment.

Should you have any questions or problems, contact:

## FISHER RESEARCH LABORATORY

1465-H Henry Brennan, El Paso, Texas 79936 Tel 915.225.0333 Fax 915.225.0336 www.fisherlab.com email:info@fisherlab.com

FRL 8708002000 04-29-09