

PARTS LIST FOR
J. C. HIGGINS
MODEL 35
.22 CALIBER PUMP-ACTION RIFLE

IDENTIFICATION NUMBER

583.3500

This number is the Identification Number of your Model 35 .22 Caliber Rifle. It will be found on the left side of barrel, just forward of receiver. Always mention this Identification Number when communicating with us regarding the Model 35 Rifle or when ordering parts.

PRICE LIST REFERENCE


REFER TO THE AUTHORIZED PRICE LIST 583.00 FOR CURRENT SELLING PRICES AND ORDERING INFORMATION.

Filing Instructions

File this Parts List immediately after Parts List Numbers 583.3401 in the Division 6 Standard Nomenclature Grey Binder.

SEARS, ROEBUCK AND CO.—U.S.A.
IN CANADA: SIMPSONS-SEARS, LIMITED

October, 1962



PARTS LIST FOR
J.C. HIGGINS MODEL 35 .22 CALIBER PUMP-ACTION RIFLE
583.3500

WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION AS SHOWN IN THIS LIST:

1. THE PART NUMBER.
2. THE PART NAME.
3. THE MODEL NUMBER.
4. THE IDENTIFICATION NUMBER

All parts identified with a dagger (†) must be fitted to the gun by gunsmiths in Sears gunshops, or by qualified gunsmiths. Do not order repair parts by key number, always use the part number.

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	3530	†Action Bar Assembly	38	328	Magazine Cap Pin
2	4006-M	Action Bar Locking Lever Assembly	39	3417	Magazine Follower
3	4014	Action Bar Locking Lever Spring	40	4040	Magazine Spring
4	3510	Barrel	41	4018	Magazine Support
5	3511	Bolt	42	338	Magazine Support Pin
5A	3533	Bolt Assembly	43	3435	Magazine Throat & Pin Assy.
6	620	Butt Plate	44	350	Magazine Throat Retaining Pin
7	345	Butt Plate Screw (2)	45	4070	Magazine Tube, Outer
8	792	Butt Plate Trim	46	3420	Magazine Tube, Inside
9	3412	Cartridge Lifter	NI	3432	Magazine Tube, Inside Assembly (Complete)
10	308	Cartridge Lifter Pin	47	401	Pistol Grip Cap
11	460	Cartridge Lifter Spring	48	403	Pistol Grip Cap Screw
12	4026	Cartridge Lifter Spring Retaining Pin	49	402	Pistol Grip Cap Trim
13	3413	Cartridge Cut Off Spring	50	3513	†Receiver & Insert Assembly (Not Sold As Replacement Part)
14	4028-M	†Disconnecter Assembly	51	524	Receiver Shoe
15	463	Disconnecter Spring	52	525	Receiver Shoe Screw
16	4012	Disconnecter Spring Retaining Pin	53	3479	Rear Sight
17	4011	Disconnecter Spring Retaining Washer	54	479	Rear Sight Elevator
18	4030	Ejector	55	150	Receiver Tang
19	4039	Ejector Retaining Pin	56	4043	Safety Button
20	509	Extractor RH	57	4044	Safety Button Plunger
21	466	Extractor Retaining Pin	58	360	Safety Button Plunger Spring
22	523	Extractor Spring	59	428	†Sear
23	468	Firing Pin	60	4026	Sear Pin
24	469	Firing Pin Retaining Pin	61	351	Sear Spring
25	320	Firing Pin Spring	62	3534	Stock Assembly
26	3512	Forearm	63	353	Stock Bolt
27	4019	Forearm Screw	64	354	Stock Bolt Lockwasher
28	4020	Forearm Stud	65	182	Stock Bolt Washer
29	3477	Front Sight, High	66	424	Stock Washer
30	4072	Hammer	67	427-M	Trigger and Trigger Extension Assembly
30A	4078	Hammer Assembly	68	359	Trigger Pin
31	325	Hammer Pin	69	360	Trigger Spring
32	326	Hammer Spring	70	3514	Trigger Guard
33	327	Hammer Spring Guide	70A	3536	Trigger Guard Assembly (Complete)
34	328	Hammer Spring Pin	71	376	Trigger Guard Retaining Pin
35	328	Hammer Strut Pin	72	377	Trigger Guard Retaining Pin Spring
36	178	Initial Plate			
37	331	Magazine Cap			